
Wipe up spills immediately. Avoid brake fluid contact with skin or eves. If it comes in contact with your eves, wash them out with clean water and immediately call a doctor. If it comes in contact with your skin, wash with clean water and, if necessary, call a doctor.

Rear Brake Fluid Level



Remove the right side cover (page 72).

With the ATV in an upright position, check the fluid level.

It should be between the UPPER (2) and LOWER (3) level mark. If the level is at or below the LOWER level mark, check the brake pads for wear (page 150).

Worn brake pads should be replaced. If the pads are not worn, have your brake system inspected for leaks.

## **Other Inspections**

- Make sure there are no fluid leaks.
- Check for deterioration or cracks in the hoses and fittings. If the hoses are worn or cracked, have them replaced by your dealer.