

# Is Your ATV Ready to Ride?

---

## Pre-ride Inspection

Check the following items before you get on the ATV:

- |                                       |  |
|---------------------------------------|--|
| <i>Engine Oil</i>                     | Check the level and add oil if needed (page 102).<br>Check for leaks.  |
| <i>Fuel</i>                           | Check the level and add fuel (page 97) if needed. Also make sure the fuel fill cap is securely fastened.<br>Check for leaks.                           |
| <i>Tires</i>                          | Use a gauge to check the air pressure. Adjust if needed. Also look for signs of damage or excessive wear (page 126).                                   |
| <i>Drive Chain</i>                    | Check the condition and slack. Adjust and lubricate if needed. Also check the chain slider and chain roller for wear and replace if needed (page 135). |
| <i>Nuts &amp; Bolts</i>               | Check the wheels to see that the axle nuts are tightened. Use a wrench to make sure all accessible nuts, bolts, and fasteners are tight.               |
| <i>Underbody &amp; Exhaust System</i> | Check for, and remove, any dirt, vegetation or other debris that could be a fire hazard or interfere with the proper operation of the vehicle.         |
| <i>Leaks, Loose Parts</i>             | Walk around your ATV and look for anything that appears unusual, such as a leak or loose cable.  |