


Switches *(Continued)*

VFR1200XD/XDA




 **Hazard switch**

 **P.32**

Shift up switch (+)

To shift up the gear.  **P.55**

**Headlight dimmer/
Passing light control switch**

-  : High beam
-  : Low beam
-  : Flashes the high beam headlight.


 **Turn signal switch**

 **P.34**

Shift down switch (-)


To shift down the gear.

 **P.55**



 **Horn button**

 **Torque Control switch**

Torque Control level setting and
Torque Control on/off.  **P.43**