

Front Wheel

Removal

1. VFR1200X/XD

Place your motorcycle on a firm level surface.

VFR1200XA/XDA

Place your motorcycle on its center stand on a firm, level surface.

- Cover both sides of the front wheel and brake caliper with protective tape or cloth.
- On the left side, remove the mounting bolts and remove the brake caliper.

- On the right side, remove the mounting bolts and remove the brake caliper.
 - Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
 - Avoid getting grease, oil, or dirt on the disc or pad surfaces.
 - Do not pull the brake lever or push the brake pedal while the brake caliper is removed.
 - Take care to prevent the brake caliper from scratching the wheel during removal.

