

Gauges, Indicators & Displays

- 4. To set the hour, push the button until the desired hour is displayed.
 - The time is advanced by one hour, each time the button is pushed.



5. Push and hold the button for more than 2 seconds. The minute display will start flashing.



(cont'd)