Seat Removal

Installation

- 1. Insert the tabs (10) into the recess under the frame.
- 2. Install and tighten the seat mounting bolts C.
- 3. Install the rear seat.
- Install the seat mounting bolts B and seat strap. Tighten the seat mounting bolts B to the specified torque: 16 lbf·ft (22 N·m, 2.2 kgf·m)

- 5. Install the seat mounting bolt A and collar.
- 6. Tighten the seat mounting bolts securely.
- Be careful not to scratch the rear fender during seat installation or removal.
- Be careful not to get the seat caught between the stay and bolts while installing the seat.