## **Clutch System**


Your motorcycle's manually activated, wet, multiplate clutch is part of the primary drive system. Proper freeplay adjustment allows a smooth, gradual engagement when shifting gears.

Improper freeplay adjustment can cause premature clutch wear.

## **Clutch Freeplay**

Refer to  $Safety\ Precautions$  on page 62 .

LEFT HANDLEBAR



(1) clutch lever