Tires

The recommended "cold" tire pressures are:

front	33 psi (225 kPa ,
	2.25 kgf/cm ²)
rear	41 psi (280 kPa ,
	2.80 kgf/cm ²)

Inspection

Refer to Safety Precautions on page 62.

Whenever you check the tire pressures, you should also look for:

- Bumps or bulges in the side of the tire or the tread. Replace any tire that has a bump or bulge.
- Cuts, slits, or cracks in the tires. Replace the tire if you can see fabric or cord.
- Nails or other foreign objects embedded in the side of the tire or tread.
- Excessive tread wear.