

| | |
|--|---------|
| Storage | |
| Compartment | 29 |
| Equipment | 29 |
| Storing Your Motorcycle | 104 |
| Switches | 22 |
| | |
| T | |
| Throttle | 75 |
| Tires | |
| Air Pressure | 45 |
| Puncture | 83 |
| Replacing..... | 45, 83 |
| Tool Kit | 30 |
| Transporting Your Motorcycle | 105 |
| Tripmeter | 18, 100 |
| Troubleshooting | 79 |
| Turn Signal Indicator | 21 |
| Turn Signal Switch | 22 |
| | |
| V | |
| Vehicle Identification Number | 107 |
| | |
| W | |
| Warning Indicators On or Flashing | 82 |
| | |
| Warranty Coverage and Service | 116 |
| Washing Your Motorcycle | 101 |
| Weight Limit | 15, 121 |
| Wheels | |
| Front Removal | 84 |
| Rear Removal..... | 88 |