Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ▶ P. 34

Tires and wheels	Check the air pressure (→ P. 45), examine tread for wear and damage (→ P. 45), and check the wheels for damage.
Fluid levels	Check the engine oil level (⇒ P. 54), engine coolant level (⇒ P. 58), and brake fluid level (⇒ P. 60), final drive oil level (⇒ P. 70).
Lights	Check that the headlight, brake light, taillight, turn signals and license plate light are working properly.
Controls	Check the freeplay of the clutch lever (⇒ P. 66), throttle grip (⇒ P. 74), and rear brake pedal (⇒ P. 62).
Fuses	Check that you have a full supply of spare fuses.
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.