

## If Your Engine Quits or Won't Start

| SYMPTOM: <b>Starter motor works, but the engine won't start.</b> |   |
|--|---|
| POSSIBLE CAUSE   | WHAT TO DO  |
| out of fuel  | Fill the fuel tank.   |
| flooded engine   | See <i>Flooded Engine</i> (page 39 ).   |
| loose or unconnected spark plug caps                             | Install the spark plug caps securely. If the engine still won't start, see your dealer. |
| loose battery cables   | Tighten the battery terminal bolts.   |
| weak battery   | Charge the battery (page 134 ). If charging doesn't help, see your dealer.              |