- **8.** Move the wheel to the right to separate it from the final drive gear case.
- 9. Remove the wheel.
  - Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
  - Avoid getting grease, oil, or dirt on the disc or pad surfaces.
  - Do not push the brake pedal while the brake caliper is removed.

## Installation

Before installing the wheel, check that the wheel hub and final drive gear splines are coated with molybdenum disulfide paste.

## Recommended molybdenum disulfide paste:

(USA only) Pro Honda Moly 60 Paste or equivalent

- **1.** Position the wheel between the swingarm and the final drive gear case.
  - Be sure the splines on the wheel hub fit into the final drive gear case.
- 2. Install the side collar into the wheel hub.
- **3.** Install the rear brake bracket, washer, bolt and rear brake bracket bolt.