

Overheats.....	82	Headlight Dimmer Switch.....	26
Starting.....	30	Helmet Holder.....	38
Stop Switch.....	26, 92	High Beam Indicator.....	25
Stopping.....	92	High Coolant Temperature Indicator.....	24
Environment.....	97	Honda Contacts.....	108
F		Horn Button.....	26
Flooded Engine.....	32	I	
Frame Number.....	98	Ignition Cut-off System	
Front Box.....	40	Side Stand.....	77
Fuel		Ignition Key.....	91
Gauge.....	19	Ignition Switch.....	27, 92
Recommended.....	35	Indicators.....	24
Remaining.....	19	Information Record.....	114
Tank Capacity.....	35	Instruments.....	18
Fuses.....	53, 89	L	
G		Labels.....	7
Gasohol.....	105	Load Limits.....	15
Gasoline.....	35	Loading Guidelines.....	15
H		M	
Headlight Aim.....	79	Maintenance	