

Overheats	82
Starting.....	30
Stop Switch.....	26, 92
Stopping.....	92
Environment.....	98

F

Flooded Engine	32
Frame Number	99
Front Box.....	40

Fuel

Gauge.....	19
Recommended.....	35
Remaining.....	19
Tank Capacity	35
Fuses	53, 89

G

Gasohol.....	106
Gasoline.....	35

H

Headlight Aim.....	79
--------------------	----

Headlight Dimmer Switch.....	26
Helmet Holder	38
High Beam Indicator	25
High Coolant Temperature Indicator.....	24
Honda Contacts.....	109
Horn Button.....	26

I

Ignition Cut-off System	
Side Stand.....	77
Ignition Key	91
Ignition Switch	27, 92
Indicators	24
Information Record.....	115
Instruments.....	18

L

Labels	7
Load Limits.....	15
Loading Guidelines	15