## INSTRUMENTS AND INDICATORS

The indicators are in the speedometer, above the headlight. Their functions are described in the table on the following page.

- (1) Speedometer
- (2) Odometer
- (3) Tripmeter
- (4) Turn signal indicator
- (5) High beam indicator (6) Neutral indicator
- (7) Tripmeter reset knob



