

## Changing Air Cleaner Element

Use a new Honda Genuine air cleaner element or an equivalent specified for your motorcycle.

### NOTICE

Using the wrong air cleaner element can result in serious damage to the engine.

1. Remove the left side cover. [2 P. 48](#)
2. Remove the air cleaner element by releasing the set spring.
3. Install a new air cleaner element.
  - u Make sure the air cleaner element is installed securely.
4. Install the left side cover.

