

Horn · Winker Switch

(Subjected by Service Bulletin of number up to F.5.1-3)

Ref. No.	Group	Part No.	Description	No. Reqd.	No. Used on		Price		
					From	To	\$	d	Yen
		1004841A ...	Horn button & dimmer switch ass'y.....	1		C100-59-12714			
			(1004841A is superseded by 1004841B with 1005214.)						
	A ...	1004841B ...	Horn button & dimmer switch ass'y.....	1	C100-59-12715				
1	B ...	1004841-1A	Horn switch upper case	1					
2	B ...	1004841-2A	Horn switch bottom case	1					
3	B ...	1004841-3-1B	Terminal ass'y, horn switch ...	1					
4	B ...	1004841-3-2A	Contact holder, horn switch ...	1					
5	B ...	1004841-3-5A	Contact spring, horn switch ...	2					
6	B ...	1004841-3-6A	Click ball, horn switch.....	2					
7	B ...	1004841-3-7	Side ball, horn switch	2					
8	A ...	1004841-3-8A	Horn switch knob	1					
9	A ...	1004841-3-9A	Horn switch contact.....	1					
10	B ...	1004841-3-10	Click spring, horn button	2					
11	B ...	1004841-3-11	Holder spring, horn	2					
12	B ...	1004841-4-1	Push button, horn	2					
13	B ...	1004841-4-2	Spring, horn button	2					
	A ...	1004845	Winker switch ass'y	1					
	A ...	Y1004845 ...	Winker & Horn button switch ass'y	1					
14	B ...	1004845-1 ...	Winker switch upper case	1					
15	B ...	1004845-2A	Grip metal lower half	1		C100-59-12714			
	B ...	1004845-2B	Grip metal lower half	1	C100-59-12715	C100-60-130365			
	B ...	1004845-2C	Grip metal lower half	1	C100-60-130366				
16	B ...	1004845-3-1A	Terminal ass'y winker switch ...	1		C100-60-130365			
	B ...	1004845-3-1B	Terminal ass'y winker switch...	1	C100-60-130366				
17	B ...	1004845-3-2A	Contact holder, winker switch	1					
18	A ...	1004845-3-8	Winker switch knob.....	1					
19	B ...	1004845-3-9	Winker switch contact.....	1					
	B ...	JP 516	Cross screw, 5×16 (0.20×0.60)...	2					
	B ...	JP 530	Cross screw, 5×30 (0.20×1.00)...	2					

MEMO.

5-1