



ENGINE WILL NOT START OR IS HARD TO START	18-2	DIFFICULT SHIFTING	18-6
ENGINE LACKS POWER	18-3	ENGINE NOISE	18-6
POOR PERFORMANCE AT IDLE AND LOW SPEED	18-4	MOTORCYCLE PULLS TO ONE SIDE	18-7
POOR HIGH SPEED PERFORMANCE	18-5	FAULTY FRONT & REAR SHOCK ABSORBERS	18-7
SMOKING EXHAUST	18-6	FAULTY BRAKE	18-7
FAULTY CLUTCH	18-6	ELONGATED DRIVE CHAIN	18-7