



RADIATOR GRILL

REMOVAL

Remove the six radiator grill/side grill mounting special bolts.
Remove the radiator grill forward.



Remove the side grill mounting bolt and mounting rubber, then remove the side grill.



INSTALLATION

Installation is in the reverse order of removal.

