

**▲ WARNING**

- Gasoline is extremely flammable and is explosive under certain conditions. Work in a well ventllated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.

**REQUISITE SERVICE**

- Fuel tank removal/installation (page 2-4)
- Air cleaner case removal/installation (page 6-3)
- Carburetors draining

PROCEDURE		Q'ty	REMARKS
	<b>REMOVAL ORDER</b>		
(1)	Insulator band	4	• Installation is in the reverse order of removal. Only loosen the screws.
(2)	Choke cable	1	
(3)	Throttle cable	2	
(4)	Fuel tube	1	
(5)	No. 10 vacuum tube (from the AVCV)*	1	California Model Only
(6)	No. 4 tube (from the AVCV and PCV)	2	California Model Only
(7)	Carburetors	1	
(8)	Insulator	4	Each insulator has the identification number as shown. At installation, align the insulator groove with the engine lug, with the ↑ UP mark facing upwards (carbretor side).