

TROUBLESHOOTING

No spark at all plugs (Faulty input system)

- If there is no spark at all plugs, the problem could be at the input of the ignition system (pulse generator, power input circuit of the spark unit, neutral switch, side stand switch or spark unit).

