

Requisite Service

- Engine oil draining/refill

Procedure		Q'ty	Remarks
	Removal Order		Installation is in the reverse order of removal.
(1)	Clutch cable	1	
(2)	Clutch cover bolt	9	
(3)	Clutch cover	1	
(4)	Gasket	1	
	Clutch Lifter Disassembly Order		Assembly is the reverse order of disassembly
(5)	Clutch lifter rod	1	
(6)	Return spring	1	Drive in a new spring pin using a pin driver until the pin does not interfere with the lifter arm as shown.
(7)	Spring pin	1	
(8)	Clutch lifter arm	1	
(9)	Oil seal	1	