

## CONTENTS

<b>3-1 GENERAL DESCRIPTION</b> .....	22
<b>DESCRIPTION</b> .....	22
<b>SPECIFICATIONS</b> .....	22
<b>DIAGNOSIS</b> .....	24
<b>3-2 LUBRICATION SYSTEM</b> .....	26
a. Description .....	27
b. Disassembly .....	28
c. Inspection .....	29
d. Reassembly .....	30
<b>3-3 CAMSHAFT DRIVE</b> .....	32
a. Description .....	32
b. Disassembly .....	32
c. Inspection .....	35
d. Reassembly .....	36
<b>3-4 CYLINDER HEAD</b> .....	39
a. Description .....	39
b. Disassembly .....	39
c. Inspection .....	39
d. Reassembly .....	42
<b>3-5 PISTON AND CYLINDER</b> .....	43
a. Description .....	43
b. Disassembly .....	43
c. Inspection .....	44
d. Reassembly .....	45
<b>3-6 CRANKSHAFT AND CONNECTING ROD</b> .....	46
a. Description .....	46
b. Disassembly .....	46
c. Inspection .....	47
d. Reassembly .....	50
<b>3-7 PRIMARY DRIVE</b> .....	53
a. Description .....	53
b. Disassembly .....	53
c. Inspection .....	53
d. Reassembly .....	54
<b>3-8 KICK STARTER</b> .....	54
a. Description .....	54
b. Disassembly .....	55
c. Inspection .....	55
d. Reassembly .....	55