

DISASSEMBLY

Remove the screws and combination meter lower case.



Remove the rubber cover and bulb sockets.



Remove the screws and combination meter upper case.

