

# 21. TROUBLESHOOTING

ENGINE DOES NOT START OR IS  
HARD TO START

21-1

ENGINE LACKS POWER

21-2

POOR PERFORMANCE AT LOW  
AND IDLE SPEED

21-3

POOR PERFORMANCE AT HIGH  
SPEED

21-4

POOR HANDLING

21-4

## ENGINE DOES NOT START OR IS HARD TO START

