



## MAINTENANCE


Install the direct ignition coils.  
Connect the direct ignition coil connectors.



Install the radiator by aligning the grommet and frame boss.



Install the horn mounting stay, washer and radiator upper mounting bolt.  
Install the wire band.



Install the radiator lower mounting bolt, washer and nut.  
Tighten the nut securely.

