

## CRANKCASE/TRANSMISSION

---

Tighten the bolts securely.

Install the removed parts in the reverse order of removal.

