

Connect RC valve control cable, cylinder head water hose, radiator bypass tube and spark plug cap to rear cylinder

Install the following parts:

- L. crankcase cover
- radiator reserve tank
- exhaust chamber
- radiator
- oil tube
- carburettor (4-14)

* Install wiring and harness correctly
(1-23)

Insert radiator fluid (5-4)
Insert transmission oil (2-9)

Perform the following inspections/
maintenance

- throttle grip play (2-15)
- clutch lever play (2-7)
- drive chain (2-9)
- oil pump control cable (2-14)

Install the following parts:

- air cleaner case
- battery (16-3)
- fuel tank (4-2)

Bleed transmission system (3-4)
Adjust RC valve control cable (2-17)
Install lower fairing, side covers, seat
(section 15)

