

---

TOOLS:

Special Tools

Lock nut wrench	07GMA-KT70200	Bearing remover (15mm)	07936-KC10000
Rr cushion Comp. Attach	07959-MB10000	- Remover assy (15mm)	07936-KC10500
Needle bearing remover	07GMD-KT80100	- Remover shaft (15mm)	07936-KC10100
Driver shaft B	07964-MB00200	- Remover head (15mm)	07936-KC10200
Needle brg driver attac	07HMD-KV30100	- Remover steering weight	07741-0010201

Standard tools

Outer driver (32x35mm)	07746-0010100	Bearing remover shaft	07746-0050100
Outer driver (42x47mm)	07746-0010300	Bearing remover head (17mm)	07746-0050500
Outer driver (24x26mm)	07746-0010700	Bearing remover head (20mm)	07746-0050600
Pilot (15mm)	07746-0040300	Driver handle A	07749-0010000
Pilot (17mm)	07746-0040400	Rear cushion compressor	07GME-0010000
Pilot (20mm)	07746-0040500	- Compressor screws assy	07GME-0010100

TROUBLE SHOOTING

Rear Wheel Runout

- wheel rim shaped changed
- rear wheel bearings collapsed
- tires faulty
- axle incorrectly tightened
- tire pressures faulty
- rear fork pivot bearings faulty
- tires worn
- wheel balance incorrect

. Rear Cushion Noisy

- cushion case out of shape
- bolts loose

Rear Cushion Too Soft

- cushion spring warped
- rear cushion adjuster incorrectly adjusted
- rear damper warped, oil leakage

Rear Cushion Hard

- damper rod bent
- rear fork pivot bearing worn
- rear cushion adjuster incorrectly adjusted