

## INSTALLATION

Do not insert rear fork pivot adjuster bolt as far as the pointed end will meet the frame internal face.

Install rear fork and insert pivot bolt from adjuster bolt side

Turn pivot bolt and tighten adjuster bolt

Torque: 1.0-2.0 kg-m

Install lock nut and tighten

Special Tool:  
Lock nut wrench

07GMA-KT70200

\* To tighten lock nut do not turn adjuster bolt at the same time and push in pivot bolt

