

		1 Month	6 Months	12 months	
CHAIN AND SPROCKET	Chain slack	●	●	●	Use side stand and measure play in middle 15-23mm
	Sprocket installation & damage		●		
IGN	Ignition plug performance	●	●	●	Plug gap 0.7-0.8mm
	Ignition plug replacement			●	5,000km (every)
BAT WIRE	Terminal connections		●		
	Connections & wire damage		●		
BODY	Twisting, foreign sounds	●	●		
	Low/High speed performance	○	●	●	Idle speed 1200 = 100rpm
	Exhaust gas		●	●	
	Air cleaner element		●	●	
	Oil leakage and capacity		●	●	Oil capacity Check that pilot lamp does not shine
	Oil leakage		●	●	
	Oil capacity	●			
	Oil cleaner clogging			●	
	Oil pump performance	○	○	○	
FUEL SYS	Fuel leakage		●	●	
	Carburettor link			●	
	Throttle cable & choke cable			●	
	Fuel filter clogging			●	
	Fuel capacity	●			
	Fuel hose replacement			●	Every 4 years
COOLING SYS	Water capacity	●	●	●	Between upper and lower levels in reserve tank
	Water leakage	●		●	
	Radiator cap			●	Pressure 1.1-1.4 K/cm ²
	Cooling agent replacement			●	Every two years
			●	●	
		●			