


# NSR250R(J)

Assemble drive gear plate and retaining clip to oil pump shaft



Ensure all O rings are in good condition and install oil pump

