

NSR250R(K)

MAINTENANCE SCHEDULE

		Continuous	1 Mths	6 Mths	12 Mths		
STEERING	Handlebars/Stems/Forks	- Play			●		
		Damage			●		
		Left, Right turning			●		
		Damage			●	●	
		Fork spindle installation			●	●	Tighten steering stem
	Brake Pedal	Fork spindle movement			●	●	Tighten steering stem
		Play and performance when pushed			●	●	Play 10-20mm Pedal 20-30mm Lever
		Noise	●				
		Brake noise		○	●	●	
		Leakage, damage, installation		○	●	●	
Res. Tank	Brake hose replacement					Every 4 years	
	Fluid capacity	●	●	●		Fluid level Front between top & bottom mark Rear between top & bottom amrk	
	Damage, wear				●		
M/Cyl. Wheel cyl. Disc/caliper	Master cylinder, cylinder cap, dust seal, disc caliper replacement					☆ Every two years	
	Disc to pad clearance				●		
Brake Disc/pads	Pad wear		○	●		Indicator	
	Disc wear and damage				●	Standard : F - 4.0mm R - 5.0mm Ser.limit : F - 3.5mm R - 4.0mm	
	Brake fluid replacement					Every year	