
Movable Drive Face Disassembly/Assembly



Requisite Service

· Movable drive face removal/installation (page 8-5)

| Procedure | | Q'ty | Remarks |
|-----------|--------------------|------|---|
| | Disassembly Order | | Assembly is in the reverse order of disassembly. |
| (1) | Bolt | 3 | |
| (2) | Face seal | . 1 | |
| (3) | Ramp plate | . 1 | |
| (4) | Slide piece | 3 | · |
| (5) | Weight roller | 6 | NOTE |
| (6) | Movable drive face | 1 | Do not apply grease to the movable drive face and weight rollers. |