

# Troubleshooting

## Battery Overcharging

- Faulty regulator/rectifier
- Broken regulator/rectifier ground wire or faulty connection.

## Battery undercharging

### NOTE

• In order to obtain accurate test readings for charging system, the battery must be fully charged and in good condition. See Common Service Manual section 22 for check the battery condition.

