

FRAME	LOCATION	MATERIAL	REMARKS
	Front wheel dust seal lips Rear wheel dust seal lips Rear wheel side collar inner surfaces Driver footpeg sliding area Passenger footpeg sliding area Throttle grip pipe flange Seat catch hook sliding area Gearshift pedal link tie-rod ball joints Gearshift pedal pivot Rear brake pedal pivot	Multi-purpose grease	
	Side stand pivot Steering head bearings Steering head bearing dust seal lips Shock absorber dust seal lips Shock absorber needle bearing Shock arm and link dust seal lips Shock arm and link needle bearings Swingarm pivot bearings Swingarm pivot dust seal lips	Molybdenum disulfide grease	
	Shock absorber spring adjuster cam surface	Molybdenum disulfide past	
	Throttle cable outer inside Choke cable outer inside	Cable lubricant	
	Left handlebar grip rubber inside	Honda bond A or equivalent	
	Steering bearing adjustment nut threads	Engine oil	
	Front brake lever-to-master piston contacting area Front brake lever pivot Rear brake caliper pin bolt sliding surfaces Rear brake master piston-to-push rod contacting area Clutch lever pivot Clutch lever joint piece-to-push rod contacting area Clutch master piston-to-push rod contacting area	Silicone grease	
	Brake master piston and cups Brake caliper piston and piston seals Clutch master piston and cups	DOT 4 brake fluid	
	Fork dust seal and oil seal lips	Fork fluid	
	Clutch fluid reservoir mounting screw threads Fork socket bolt threads Front brake caliper assembly bolt threads Rear brake caliper pin bolt threads	Locking agent	