

## 20. KR50OR EUROPEAN/ GENERAL TYPE

## INTRODUCTION

This section contains service information for the 1982 XR500R European and general type. Refer to base shop manual for information not included in this section.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION.

HONDA MOTOR CO., LTD. Service Publications Office

## TABLE OF CONTENTS

| WIRING DIAGRAM .          |    |   |    |    |   | , |   | 20-2 |
|---------------------------|----|---|----|----|---|---|---|------|
| CABLE AND HARNESS         | R  | 0 | U. | TI | N | G |   | 20-3 |
| HANDLEBAR SWITCHE         | S  |   |    | i  |   | à |   | 20-5 |
| <b>BRAKE STOPLIGHT SW</b> | IT | C | H  |    |   |   | Q | 20-5 |