

## TRANSMISSION

---

Align the return spring with the pin bolt and install the shift spindle while pulling the shift plate. Assemble the crankcases (Section 10). Install the shift cam plate, stopper arm (page 8-16) and gear shift pedal and check the transmission for smooth shifting.

