Parts Location



Tool kit P.39

Document bag P.39

Side cover P.64

Air cleaner P.69

Front brake fluid reservoir P.72

Front suspension spring preload adjuster P.87

Front brake lever P.86

Throttle grip P.83

Engine oil fill cap P.65

Engine oil level inspection window P.65

Engine oil filter P.67

Engine oil drain bolt P.67

Rear brake pedal

Main fuse P.107

Rear brake fluid reservoir P.72