
(1) FUEL LINE (Damage, leakage)
(20) SPARK PLUG (Wear, damage, color)
(2) AICV (Damage, faulty hose)
• Fuel tank
(19) CARBURETOR CHOKE (Operation)
(3) AIR CLEANER (Contamination, clogging, replacement, page 3-5)
• Side cover
(18) CLUTCH LEVER (Free play)
(17) STEERING HEAD BEARING (Damage)
(4) SUSPENSION (Loose, wear, damage)
(16) HEADLIGHT (Aim)
(15) SUSPENSION (Loose, wear, damage)
(14) TIRE (Wear, damage, pressure)
(5) TIRE (Wear, damage, pressure)
(13) WHEEL (Damage, runout corrosion)
(6) WHEEL (Damage, runout, corrosion)
(7) DRIVE CHAIN (Free play, lubrication, replacement)
(12) OIL FILTER (Replacement)
(11) IGNITION TIMING (page 14-10)
(8) DRIVE CHIN SLIDER (Wear, damage, page 3—6)
(10) THROTTLE STOP SCREW (Idle speed adjustment)
(9) SIDE STAND (Operation)