

Tyres

For your own comfort and safety, always maintain tyres in good condition. Correct tyre pressure should be maintained at all times. Tyres worn beyond the wear indicator limit should be replaced as soon as possible.

Warning:

Excessively worn tyres and inappropriate tyre pressures may lead to an accident with fatal or serious injury.

Always observe the tyre pressure range and replace tyres worn beyond the wear indicator limits.

Tyre pressure adjustment

Measure while the tyre is cold:

Without pillion passenger	Front	150kPa(1.50kgf/cm ²)
Without pillion passenger	Rear	150kPa(1.50kgf/cm ²)
With pillion passenger	Front	150kPa(1.50kgf/cm ²)
With pillion passenger	Rear	150kPa(1.50kgf/cm ²)

Wear indicator check

Tyre Tread depth can be checked by looking at the wear indicator. If the wear indicators come out to the surface, replace the tyre as soon as possible.

In addition to this, for your safe riding, always replace the tyre if the tread centre depth become less than the figures below:

Front tyre: 3.0mm

Rear tyre: 3.0mm

