

This section tells you how to fine tune your CRF for maximum competition performance.

Initial suspension adjustments should be performed after a minimum of 2 hours of easy break-in time.

Optional front and rear suspension springs are available in order to tailor your CRF specifically for your weight, riding style and course conditions.

Follow the instructions given in the rear suspension sag setting section of *Rear Suspension Adjustments* to determine if your combined rider and sprung machine weight (rider fully dressed for competition and machine coolant, oil and fuel levels ready for competition) requires an optional stiffer or softer rear spring. The need for either optional rear spring may need to be balanced by installing the optional fork springs of a similar rate.

Engine Mode Select Button	140
Current Mode	140
Mode Selection	140
Honda Selectable Torque Control.....	141
Current Mode	141
Mode Selection	141
HRC-Launch Control System	142
Front Suspension Adjustments	143
Front Suspension Air Pressure.....	143
Front Suspension Damping.....	144
Fork Springs.....	144
Fork Oil Adjustment	145
Rear Suspension Adjustments.....	146
Rear Suspension Spring Pre-Load	146
Rear Suspension Damping.....	147
Rear Suspension Race Sag.....	149
Suspension Adjustments for	
Track Conditions.....	151
Suspension Adjustment Guidelines	152
Tuning Tips.....	155
Spark Plug Reading	155
Chassis Adjustments	156
Rear End	156
Fork Height/Angle	156
Wheelbase.....	156
Gearing.....	157
Tire Selection for Track Conditions	158
Personal Fit Adjustments	159
Control Positioning.....	159
Handlebar Position, Width & Shape.....	159