Symptom	Cause/remedy
Unable to pair <i>Bluetooth</i> ® device	Some <i>Bluetooth</i> [®] devices and application software you use may be incompatible with the audio system and/or the operable functions may be limited.
	Check that the audio system and <i>Bluetooth</i> [®] device are both in the pairing mode. ➡ P. 82, 86
	The audio system may not be properly connected when another <i>Bluetooth</i> [®] device is being paired at the same time. Check your surroundings to make sure no other device being paired is present before re-pairing. Presence of a <i>Bluetooth</i> [®] device in the vicinity sometimes affects the pairing due to radio wave interference, etc.
	When connecting a <i>Bluetooth</i> [®] device, make sure no other <i>Bluetooth</i> [®] device readied for pairing is present. Presence of a <i>Bluetooth</i> [®] device in the vicinity sometimes affects the pairing due to radio wave interference, etc.
	When you repeatedly fail in pairing, delete the paired device once, then try pairing again. P. 82, 84
Unable to connect <i>Bluetooth</i> ® device	Depending on the <i>Bluetooth</i> [®] device and application software you use, it may take some time for the audio system to connect to a device and to start playing an audio file.
	The connection may be temporarily disconnected when starting the engine, which is normal and not a malfunction. The <i>Bluetooth</i> [®] device will be reconnected after the engine is started.
	Check that your <i>Bluetooth</i> [®] device has been paired. Referring to the instruction manual of your <i>Bluetooth</i> [®] device, check that your <i>Bluetooth</i> [®] device is in connectable state.