Reverse Lock System

Measure the reverse assist lever (2) free play. Free play, measured at the lever (2) end near the cable (Fig. 4-17), should be approx:

2-4 mm (0.1-0.2 in)

To adjust, loosen the lock nut (3) and turn the adjusting nut (4). Tighten the lock nut securely.

Other Checks:

Check the reverse assist lever and cable for loose connections or other damage. If the cable is worn or kinked, have it replaced by your Honda dealer.




Fig. 4-17

- (1) Rear brake lever
- (2) Reverse assist lever
- (3) Lock nut
- (4) Adjusting nut

While reading this manual, remember:

▲W ARNING

Indicates a strong possibility that serious injury or death may result if instructions are not followed.