
Tire Puncture ► Removing Wheels

Installation

- 1. Attach the side collars to the wheel.
- 2. On the left side, place the wheel between the fork legs and insert the lightly greased front axle shaft to the end, through the left fork leg and wheel hub.
- **3.** Align the end of the front axle shaft with the surface of the fork leg.



- **4.** Tighten the left axle pinch bolts to hold the axle.
- **5.** Tighten the axle bolt.

Torque: 44 lbf·ft (59 N·m, 6.0 kgf·m).

- **6.** Loosen the left axle pinch bolts.
- **7.** Tighten the right axle pinch bolts.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m).

8. Install the right brake caliper and tighten the mounting bolts.

Torque: 33 lbf·ft (45 N·m, 4.6 kgf·m).