



Front Suspension Adjustments

28. Install the front visor by aligning its grommets (36) with the tabs (37) on the steering stem.




(36) front visor grommets (37) tabs

29. Install and tighten the front visor bolts (38). Install the handlebar pad (39).



(38) front visor bolts (39) handlebar pad

30. With the front brake applied, pump the fork up and down several times to seat the axle and check front brake operation.




31. While keeping the forks parallel, alternately tighten the right axle pinch bolts (40) to the specified torque:
15 lbf·ft (20 N·m, 2.0 kgf·m)

NOTICE


To avoid damage when torquing the axle pinch bolts, be sure the axle is seated firmly onto the left fork leg clamp inner surface.

32. Install the tripmeter cable (41) and tighten the lock nut securely.




(40) right axle pinch bolts (41) tripmeter cable

33. Install the disc cover (42) and tighten the bolts (43) to the specified torque:
10 lbf·ft (13 N·m, 1.3 kgf·m)



(42) disc cover (43) bolts

34. Turn the rebound damping (44) and compression damping (45) adjuster back to their original setting.



(44) rebound damping adjuster

(45) compression damping adjuster