


Carburetor Adjustment

NOTE: Before making adjustments to the carburetor, be sure the ignition system is functioning properly and the engine has good compression. Do not attempt to compensate for other faults by carburetor adjustment.

A carburetor which is out of adjustment will adversely affect the performance of the engine; therefore, it is important that the carburetor always be maintained in perfect adjustment.

1. Start and warm up the engine to normal operating temperature.
2. Set the engine idle speed to **900 rpm** by adjusting the stop screw 1. Turning the stop screw in the A direction will increase the rpm, and turning in the B direction will result in a decrease.

3. If the proper idle speed cannot be obtained after performing the adjustment in section "1" and "2" above, see your authorized HONDA dealer.



① Stop screw