

## **Rear Wheel Installation**

To install the rear wheel, reverse the removal procedure.

1. Tighten the rear wheel nuts securely in the same crisscross pattern to the specified torque:

108 N·m (11.0 kgf·m , 80 lbf·ft)

2. Reinstall the muffler and muffler cover.

- Before installing the muffler, replace the muffler gasket with a new gasket.
- If either of the rubber caps came away from the prongs when removing the muffler cover, re-attach them.

Tighten and torque the nuts and bolts to the specified torque:

Muffler bracket bolt:

21 N·m (2.1 kgf·m , 15 lbf·ft)

Muffler band bolt:

17 N·m (1.7 kgf·m , 13 lbf·ft)

Muffler cover bolt:

9 N·m (0.9 kgf·m , 6.6 lbf·ft)

If a torque wrench is not used for this installation, see your Honda dealer as soon as possible to verify proper assembly.