

Both left and right index notches should correspond. If the axle is misaligned, turn the left or right adjusting nut until the index notches correspond on the index marks of the same position and recheck chain slack.

6. Tighten the axle nut to:
98 N·m (9.8 kg-m, 71 ft-lb)
7. Tighten the adjusting nuts lightly, then tighten the lock nuts by holding the adjusting nuts with a spanner.


Wear inspection:

Check the chain wear label when adjusting the chain. If the red zone (6) on the label aligns with the index notch (7) on the left rear axle washer after the chain has been adjusted to the proper slack, the chain is excessively worn and must be replaced. The proper slack is:

15–25 mm (5/8–1 in)

CAUTION:

- * **Damage to the bottom part of the frame may be caused by excessive drive chain slack of more than:
50 mm (2 in)**



(6) Red zone

(7) Index notch