

FRONT WHEEL INSTALLATION

Install the side spacers onto the hub.

NOTE

The longer spacer is for the right side.

Install the front wheel and hub.
If the axle holder has been removed, loosely install the holder with the "UP" mark facing up.
Insert the axle into the fork slider leg and hub.
Tighten the axle.

TORQUE: 70–110 N·m
(7.0–11.0 kg·m, 51–80 ft·lb)



Tighten the upper axle holder nuts first, then tighten the lower nuts.

TORQUE: 10–14 N·m
(1.0–1.4 kg·m, 7–10 ft·lb)

Install the front brake caliper over the disc and on the fork slider being careful not to damage the pads.
Tighten the caliper mount bolts.

TORQUE: 24–30 N·m
(2.4–3.0 kg·m, 17–22 ft·lb)

Install the brake hose clamp onto the fork slider.



Install the wheel nuts with the tapered side facing in.
Lower the front wheel on the ground and tighten the wheel nuts.

TORQUE: 60–70 N·m
(6.0–7.0 kg·m, 43–51 ft·lb)

